



ISP Pin can be grounded if needed with GND Pin's

VIN, VBAT, VBUS => 3.3
VBUS = USB 5V

LPC-Link has this Resistors! Only needed for Debugger without
 TMS: Use 10K-100K Ohm pull-up resistor to VCC
 TDO: Use 10K-100K Ohm pull-up resistor to VCC
 TDI: Use 10K-100K Ohm pull-up resistor to VCC
 TCK: Use 10K-100K Ohm pull-down resistor to GND

See KEIL MCB1700 USB Device

Sept 2012 RevA

| |
|---------------------|
| MCU-Baseboard |
| AIMS2000 |
| 08.09.2012 03:59:15 |
| Sheet: 1/5 |