



6-pol. ISP-Buchse
Ansicht v. oben

- Belegung
- 1 = MISO
 - 2 = (+5)
 - 3 = SCK
 - 4 = MOSI
 - 5 = Reset
 - 6 = GND

X) Vcc-Trennstelle

A	B	C	D	1	2	3	4	5	6
1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30

Datum: 25.12.14

Blatt:
von: