

# eurolite

## **Flashlight Pro-Controller**


**Service-manual**

**Serviceunterlagen**

**Documents techniques**

**Documentos de servicio**

I. No.	Artikelbeschreibung	Article designation	Description d'article	Descripción del artículo
1 E3070801	Platine für Pro-Controller 19"	PCB for 19" Pro-Controller	Platine pour Pro-Controller 19"	Platina para Pro-Controller 19"
2 E3070802	Prozessor für Pro-Controller 19"	Processeur for 19" Pro-Controller	Processeur pour Pro-Controller 19"	Procesador para Pro-Controller 19"
3 E3070803	Netzschalter für Pro-Controller 19"	Power switch for 19" Pro-Controller	Interrupteur ON/OFF p. Pro-Controller 19"	Conmutador de alimen.p.Pro-Controller 19"
4 E3070810	Poti für Pro-Controller 19"	Poti for 19" Pro-Controller	Poti pour Pro-Controller 19"	Poti para Pro-Controller 19"
5 E3070811	Schalter für Pro-Controller 19" (Satz)	Switch for Pro-Controller 19" (set)	Interrupteur p. Pro-Controller 19" (set)	Interruptor p.Pro-Controller 19" (set)
6 E3070820	Relais für Pro-Controller 19"	Relay for 19" Pro-Controller	Relais pour Pro-Controller 19"	Réle para Pro-Controller 19"



Title		
Size	Document Number	REV
B		
Date:	July 20, 1998 Sheet	1 of 1