



*There is no official pin numbering for this type of footprint!
 So i had to choose a numbering at random.
 So it starts with one at the pin nearest to the black dot.
 Pin two is the middle pin, and pin three the last.*

Be careful and check your allocation!

1:1 Print! Check dimension by controlling the gauge!

KiCAD Footprints of some old Sowjet Aera Transistors from the file

OldSowjetAera_Transistor_RevA.mod

Author: Bernd W̄iebus / Uedem / Germany / 28 May 2013

Licence: CC-Zero / Public Domain

NO RESTRICTION ! NO WARRANTY!

<http://creativecommons.org/>



*For suggestions
 and improvements
 please contact
 me at
 bernd.wiebus@gmx.de*

File: 1		Sheet: 1/1	
Title:			
Size: A4	Date: 28 may 2013		Rev:
KiCad E.D.A. pcbnew (2013-03-30 BZR 4007)-stable			Id: 1/1