

1:1 Print! Check dimension by controlling the gauge!


KiCAD Footprints of some vertical mounted through hole electrolytic capacitors from the file Elko_ThroughHole_RevB-3_30Dec2011.mod

Author: Oliver Kirsch + Bernd Wiebus / Uedem / Germany

GNU-GPL NO WARRANTY!



Hint/Warning: The Plus symbol "+" is at the silk screen AND copper layer, too!
This may cause some problems with isolations or shortcuts, because a graphical line at a copper layer is NOT recognised by the DRC!
If you want to avoid this problems, choose the modules with the suffix "-CopperClear" in the name. There the "+" symbol is only at the silk screen layer.
But if you get boards without silk screen layer, you will have no orientation information!



Elko_vert_DM16_RM7-5_CrossMark
Experimental Footprint
with "cross-marked" +.

File: Elko_ThroughHole_RevB-3_30Dec2011.brd
Sheet: 1/1
Title:
Size: A4
Date: 25 apr 2012
KiCad E.D.A. picnew (2012-01-19 BZR 3256)-stable
4
Rev: 5
Id: 1/1