

AVRISP mkII in ISP mode with ATmega8

Main Program Fuses LockBits Advanced HW Settings HW Info Auto


Fuse	Value
RSTDISBL	<input type="checkbox"/>
WTDON	<input type="checkbox"/>
SPIEN	<input checked="" type="checkbox"/>
EESAVE	<input type="checkbox"/>
BOOTSZ	Boot Flash size=128 words Boot address=\$0F80
BOTRST	<input type="checkbox"/>
CKOPT	<input type="checkbox"/>
BODLEVEL	Brown-out detection at VCC=4.0 V
BODEN	<input checked="" type="checkbox"/>
SUT_CKSEL	Ext. Clock; Start-up time: 6 CK + 64 ms

HIGH	0xDF
LOW	0x20


Auto read
 Smart warnings
 Verify after programming

Program Verify Read

Setting mode and device parameters.. OK!
Entering programming mode.. OK!
Reading fuses address 0 to 1.. 0x20, 0xDF .. OK!
Leaving programming mode.. OK!



RLD32S



RLD32M

AVRISP mkII in ISP mode with ATmega162

Main Program Fuses LockBits Advanced HW Settings HW Info Auto

Fuse	Value
M161C	<input type="checkbox"/>
BODLEVEL	Brown-out detection at VCC=4.3 V
OCDEN	<input type="checkbox"/>
JTAGEN	<input type="checkbox"/>
SPIEN	<input checked="" type="checkbox"/>
WDTON	<input type="checkbox"/>
EESAVE	<input type="checkbox"/>
BOOTSZ	Boot Flash size=256 words start address=\$1F00
BOOTRST	<input checked="" type="checkbox"/>
CKDIV8	<input type="checkbox"/>
CKOUT	<input type="checkbox"/>

EXTENDED	0xD9
HIGH	0xDC
LOW	0xFF

Auto read
 Smart warnings
 Verify after programming

Program Verify Read

Setting mode and device parameters.. OK!
Entering programming mode.. OK!
Reading fuses address 0 to 2.. 0xFF, 0xDC, 0xD9 .. OK!
Leaving programming mode.. OK!

AVRISP mkII in ISP mode with ATmega162

Main Program Fuses LockBits Advanced HW Settings HW Info Auto

Fuse	Value
M161C	<input type="checkbox"/>
BODLEVEL	Brown-out detection at VCC=4.3 V
OCDEN	<input type="checkbox"/>
JTAGEN	<input type="checkbox"/>
SPIEN	<input checked="" type="checkbox"/>
WDTON	<input type="checkbox"/>
EESAVE	<input type="checkbox"/>
BOOTSZ	Boot Flash size=256 words start address=\$1F00
BOOTRST	<input checked="" type="checkbox"/>
CKDIV8	<input type="checkbox"/>
CKOUT	<input type="checkbox"/>

EXTENDED	0xD9
HIGH	0xDC
LOW	0xFF

Auto read
 Smart warnings
 Verify after programming

Program Verify Read

Setting mode and device parameters.. OK!
Entering programming mode.. OK!
Reading fuses address 0 to 2.. 0xFF, 0xDC, 0xD9 .. OK!
Leaving programming mode.. OK!