


For suggestions
and improvements
please contact
me at
bernd.wiebus@gmx.de



Wire connections are just two THT pads used to lay wire connections across a board. This may be a clumsy method, but also a quick and dirty method to get rid of routing and EMI problems.
They correspond with the WIRE_CONNECTION_I_DATE15JUN2010,
WIRE_CONNECTION_I1_DATE15JUN2010 and
WIRE_CONNECTION_I11_DATE15JUN2010 symbols from
SymbolsSimilarEN60617+oldDIN617-RevXX.lib library.

1:1 Print! Check dimension by controlling the gauge!

KiCAD Footprints of some wire connections / bridges/ wire jumpers from the file
WireConnections-Bridges_RevA.mod
Author: Bernd Wiebus / Uedem / Germany / 15 June 2010



Licence: CC-Zero / Public Domain
NO RESTRICTION ! NO WARRANTY!
<http://creativecommons.org/>

File: WireConnections-Bridges_RevA.kicad_pcb		
Sheet:		
Title:		
Size: A4	Date: 6 jun 2013	Rev:
KiCad E.D.A.		Id: 1/1